



## Electrical heating battery for Renovent type CVR

Circular electrical heating battery for preheating or post-heating for **RENOVENT**

### Application

- The **CVR-VM** is used for preheating to prevent the heat exchanger from freezing. This way, the unit will not start the defrost mode. This battery can only be used for Renovent HR.
- The **CVR-VS** is used for preheating to prevent the heat exchanger from freezing. This way, the unit will not start the defrost mode. This battery can only be used for Renovent HR with an optional print or for Renovent Sky 300 or Sky 150 Plus.
- The **CVR-NM** is used for post-heating of the air that is pulsed into the rooms up to a certain temperature that is set on the unit. This battery can only be used for Renovent HR with optional print.
- The **CVR-NS** is used for post-heating of the air that is pulsed into the rooms up to a certain temperature that is set on the unit. This battery can only be used for Renovent Sky Plus.
- The **CVR-NE** is used for post-heating of the air that is pulsed into the rooms up to a certain temperature that is set on the unit. This battery can only be used for Renovent Excellent Plus.

### Order example

**CVR – NE 400 1000W**

Explanation


**CVR** = Circular electrical battery

**N** = Post-heating

**E** = Excellent

**400** = max air flow Renovent

**1000** = Heating capacity in W



A= Heating coil  
B= Maximum safety with manual reset  
C= Connection plug 230V-50Hz  
L= Led maximum safety is activated