



- RG1 - Controller EKR-K KN1 NI
- V1 - Triac
- K1 - Internal contactor
- B - Thermostat with automatic reset
- C - Thermostat with manual reset
- A - Heating elements
- S - User side circuit breakers
- TR5K - Heat and temperature control unit
- TJ-K10K - Air temperature sensor
- PS - Air pressure switch

3x400V+N