



## Circular spare filters G4 for SF type SF-SP

Circular spare filters G4 for **SF**

### Order example

#### ■ SF-SP, 160

Explanation

**SF-SP** = Spare filter for SF

**160** = SF connection diameter