


Smarty 2X P* / 3X P / 4X P versions v1.1 / v1.2**

* - 2X P does not have constant air flow/pressure functions

** - v.1.2 version can control one heater



IV - exhaust air fan

PV - supply air fan

PR - plate heat exchanger

PF - filter for supply air

IF - filter for extract air

M1 - actuator of by-pass damper

TA - extract air temperature sensor

TL - outdoor air temperature sensor

TJ - supply air temperature sensor

EKA NIS - electric pre-heater

EKA - electric heater

PT1 - supply air fan pressure transmitter (only v1.1 version)

PT2 - exhaust air fan pressure transmitter (only v1.1 version)