



- PF** - filter for outdoor air
- PV** - supply air fan
- KE*** - electrical heater (supplied separately)
- TJ** - supply air temperature sensor
- PS** - external differential pressure switch